



NOTE: TANK HOLE TO HAVE 2" STEP TO ALLOW TREATMENT UNIT TO BE 2" LOWER THAN DOSE/TRASH TANK IN ORDER FOR 1" FALL AT EACH EXTERIOR TANK CONNECTION

TANK DIAGRAM SHOWING TOP OF TANKS  
 NUWATER BNR-600 ATU SYSTEM;

Sound PreCast

REVISED:	5/18/15
DRN BY:	NCE
DWG #	080816

